

Wallcovering Hanging Instructions

Please read these instructions carefully before hanging this wallcovering. It is advisable that a professional decorator is used.

Preparation

Walls should be dry, clean and even.

Remove any old wallpaper and loose paint.-Roughen painted surfaces with sandpaper.-For best results we recommend that walls are cross lined using a good quality lining paper. Sizing the lining paper will aid adhesion. Lining should be allowed to dry out completely before hanging the wallcovering. Pasting and Hanging

- This is a paste the wall product. The decorator should paste the wall and not the back of the wallcovering.
- A good quality, solvent free, fungicide protected ready-mixed 'tub' adhesive – specifically for paste the wall non-woven papers should be used.
- Paste should be evenly applied to the wall to hang one length at a time, to an area slightly wider than width of the paper.
- Butt joints and use a decorators brush to smooth down the wallcovering, working from the centre to the edges to express air bubbles
- Avoid squeezing paste out of the joints and ensure paste does not get onto the brush or roller.
- No paste should be allowed to come into contact with the surface and hands should be kept clean and dry whilst hanging the wallcovering.
- Paste will damage the surface. The company cannot accept responsibility for marks or damage caused by paste.
- Should any paste have been allowed to come into contact with the surface, it should be lightly sponged whilst still moist, using a clean damp sponge.

Caring for your wallpaper

Our coated non-woven wallpapers and vinyls are all “spongeable”, please be sure the sponge is slightly damp and make only very light strokes. **Do Not Rub The Paper.** Un-coated papers and specials such as Grasscloth and Silk wallcoverings should be cleaned by dusting with a clean dry brush or by brush accessory on a vacuum cleaner.